

# Assembly Instruction

## ITEM NO: SH8893GRY-2PW/SH8893BRN-2PW
## DOUBLE RECLINING LOVESEAT

**NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.**


**PARTS LIST**

| NO. | DRAWING | QTY | DESCRIPTION |
|---|---|---|---|
| **A** |  | 1 | LSF BACK REST |
| **B** |  | 1 | MIDDLE BACK REST |
| **C** |  | 1 | RSF BACK REST |
| **D** |  | 1 | SEAT |
| **E** |  | 1 | LEFT EAR |
| **F** |  | 1 | RIGHT EAR |
| **G** |  | 1 | PLUG-IN POWER SUPPLY |


**Please follow the below drawings to assemble the item.**

**Note: Left ear and right ear are stored at the bottom of arm, please take out for assembly**


**Step 1.**





**Step 2.**





**Step 3.**



**Step 4.**




**Completed.**




## CARE INSTRUCTION FOR POLYESTER FURNITURE:

**In order to maintain the original appearance of your polyester furniture, please follow below simple care procedure:**

- **Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage polyester.**
- **Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.**

**It is recommended to install protective pads under all legs and supports to avoid damage or scratches when placing furniture on a wood floor or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.**

**PLEASE KEEP ASSEMBLY INSTRUCTION FOR FUTURE REFERENCE**