




# ASSEMBLY INSTRUCTION

ITEM NO:3533RF-30 LIFT TOP CKTL TBL W 4PC CASTERS

**Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.**

PARTS LIST				HARDWARE LIST				
NO.	Description	Sketch	Q'ty	NO.	Description	Sketch	Size	Q'ty
A	TOP PANEL WITH DRAWER		1PC	1	BOLT		1/4"-20x1"	4PCS
B	SHELF		1PC	2	BOLT		1/4"-20x5/8"	6PCS
C	LSF/RSF LEG FRAME		2PCS	3	SPRING WASHER		1/4"IDx1/2"ODx1/16"	10PCS
				4	FLAT WASHER		1/4"IDx5/8"ODx1/16"	10PCS
				5	PLASTIC CAP			4PCS
				6	ALLEN KEY		5/32"	1PC
				7	CASTER		1 1/2"	4 PCS
				8	SCREW		5/32"x5/8"	16PCS


STEP 1 :




# ASSEMBLY INSTRUCTION

ITEM NO:3533RF-30 LIFT TOP CKTL TBL W 4PC CASTERS


STEP 2:



STEP 3:



STEP 4:



**CAUTION!**

Do not allow children to play on the mechanized furniture or operate the mechanism. Top surfaces fold down on closing, so that a child could possibly be injured. Always leave furniture in the closed position when unattended. To prevent the table from tipping over, do not place more than 30 pounds on the top when in the open position.

**KEEP HANDS CLEAR OF MECHANISM**

**DO NOT TIGHTEN BOLTS UNTIL COMPLETELY ASSEMBLED.**

 It is recommended to install protective pads under all legs and supports to avoid damage or scratches when placing furniture on a wood floor or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.

 Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.