

ASSEMBLY INSTRUCTIONS

SH5717/SH5717WHT-36 3 PCS PACK COUNTER HEIGHT SET - STOOL

Thank you for purchasing this product. Please take time to read and follow the instructiors below. Check that you have all parts and hardware before assembly. Parts apparently missing are often found in the packing materials. If you do not have all the parts listed, have your dealer contact us and they will be sent to you immediately.



It is recommended to install protective pads under all legs and supports to avoid damage or saratches when placing furniture on or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.

PARTS LIST					HARDWARE LIST				
A	Wooden Seat	0 0	1	1	0)	Long Bolt	1/4" x 2 1/2"	16	
				2		Spring Washer	5/16" x 1/2"	16	
В	Left Leg	© 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	2	3	0	Flat Washer	5/16" x 3/4"	16	
С	Right Leg	0 (00	2	4	Dammm	Wood Screw	4MM x 1 1/2"	16	
				5		Allen Key	4MM	1	
D	Long Stretcher		2						
			_						
E	Short Stretcher		2						
]					

HARDWARE SET ARE PACKED IN SH5717/SH5717WHT-36 FOR ASSEMBLY

