Assembly Instruction 3PC OCCASIONAL SET ITEM NO.:SH592-31

DESCRIPTION

BOLT

BOLT

LOCK WASHER

CASTER

GLASS PAD


ALLEN WRENCH

OPEN WRENCH

Part	Parts list:				Hardware list:		
NO.	DRAWING	QTY	DESCRIPTION	NO.	DRAWING	QTY	
A		1	BIG COFFEE TABLE WOOD TOP	1	()))))) 1/4" x 1/2"	24	
B		1	BIG COFFEE TABLE BOTTOM FRAME	2	3/16" x 10mm	12	
С		4	BIG COFFEE TABLE LEG	3		12	
)		1	SMALL COFFEE TABLE TOP FRAME	4	<u>G</u>	4	
E		1	SMALL COFFEE TABLE BOTTOM FRAME	5		8	
F		4	SMALL COFFEE TABLE LEG	6		1	
G	Ø 512 x 5mm	1	SMALL COFFEE TABLE GLASS TOP	7		1	
Н		1	END TABLE WOOD TOP				
I		1	END TABLE BOTTOM FRAME				
J		4	END TABLE LEG				
K	Ø 512 x 5mm	1	END TABLE GLASS SHELF				


Step 1.

Attach big coffee table legs (C) to big coffee table wood top (A) using bolts (1) and allen wrench (6) as shown.




Step 2.

Attach big coffee table bottom frame (B) to big coffee table legs (C) using bolts (2) and lock washer (3) as shown.




Step 3.

Attach small coffee table legs (F) to small coffee table top frame (D) using bolt (1) and allen wrench (6) as shown.




Step 4.

Attach small coffee table bottom frame (E) to small coffee table legs (F) using bolts (2) and lock washer (3). Then attach casters (4) to small coffee table legs (F) as shown.




Step 5.

Attach glass pad (5) to small coffee table top frame (D), then place small coffee table glass top (G) as shown.




Step 6.

Attach end table legs (J) to end table wood top (H) using bolts (1) and allen wrench (6) as shown.



Step7.

Attach end table bottom frame (I) to end table legs (J) using bolts (2) and lock washer (3) as shown.



Step 8.

Attach glass pad (5) to end table bottom frame (I), then place end table glass shelf (K) as shown.

