ASSEMBLY INSTRUCTIONS

ITEM NO: SH8895BLK-2/SH8895GRW-2 / SH8895RED-2

POWER DOUBLE RECLINER LOVESEAT W / CONSOLE, POWER HEADRESTS & LED LIGHT / SPEAKERS

NOTE: Do not use power tools for assembly. Power tool increase the risk of over tightening which lead to splitting or cracking the wood.

PARTS LIST

NO.	DRAWING	DESCRIPTION	QTY
А	200	SEAT WITH WIRE	1PC
В		LSF BACK REST	1PC
С		RSF BACK REST	1PC
D		CONSOLE BACK REST	1PC
E		LSF EAR	1PC
F		RSF EAR	1PC

HARDWARE LIST


NO.	DRAWING	DESCRIPTION	QTY
1		PLUG ADAPTER WITH WIRE	1PC
2	2	PLUG ADAPTER WITH WIRE FOR BLUETOOTH SPEAKER	1PC
3		STAR KNOB BOLT (Ø1/4" X50MM)	2PCS

Please follow the below drawings to assemble the item.

STEP 1


Align the female brackets at the back onto the male brackets at the seat, insert back rest to the seat then push to the end and make sure it is fixed in position securely. Connecting the wire from back rest to seat for power headrest.

Use star knob bolts to tighten the console back rest with the tea table box.



STEP 2


Insert ear to the backrest then push to the end and make sure it is fixed in position securely.




Please follow the below drawings to assemble the item.


STEP 3


Carefull allign & connect the plug with wire (1)(2) to the slot. make sure it connect with securely.



STEP 4







CARE INSTRUCTION FOR POLYESTER

In order to maintain the original appearance of your polyester funiture, please follow below simple care procedure:

- Avoid exposing funiture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage polyester.
- Wipe gently with a damp soft cloth to remove dust dirt and any grime build up.
- Disconnect the electrical plug from the wall outlets before cleaning, moving, servicing or when not in use for an extended period of time.
- Plug directly into a wall outlet. Do not use an extension cord or adaptor.
- Check the condition of the power transformers, electrical cords, plugs and connectors monthly. Keep the power adapter and electrical cords away from heat sources. Never operate the unit with a damaged power adapter, electrical cord, plug or connector.
- Before moving the product, please disconnect the electrical plug from the wall outlet and secure the mechanism
 to prevent unexpected opening or movement. Never move the product by the mechanism, legrest, handle, or reclining
 back.
- Do not attempt to disassemble or service the adaptor or motor. No serviceable parts are inside.
- Do not allow electrical cord to be pinched between moving parts or between the frame and the floor. Do not place cord under carpet or in location where it could become worn.
- Unplug the power cord immediately if you detect strange odors or fumes coming from the chair.